

MOUNTING STRAP
PATTE DE FIXATION

CANOPY
CACHE

INSTRUCTIONS
For Assembling and Installing Fixtures in Canada
Pour L'assemblage et L'installation Au Canada

THREADED BALL
BOULE FILETÉE

THREADED PIPE
TUBE FILETÉ

HEXNUT
ECROU HEXAGONAL

GLASS
VERRE

FLAT WASHER
RONDELLE PLATE

BOTTOM TRIM
GARNITURE INFÉRIEURE

FINIAL
ORNEMENT

1) TURN OFF POWER.

IMPORTANT: Before you start, NEVER attempt any work without shutting off the electricity until the work is done.

- Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "OFF" position.
- Unscrew the fuse(s), or switch "OFF" the circuit breaker switch(s), that control the power to the fixture or room that you are working on.
- Place the wall switch in the "OFF" position. If the fixture to be replaced has a switch or pull chain, place those in the "OFF" position.


2) Find the appropriate threaded holes on mounting strap. Assemble mounting screws into threaded holes.

3) Attach mounting strap to outlet box. (Screws not provided) Mounting strap can be adjusted to suit position of fixture.

4) Make wire connections (connectors not provided.) Reference chart below for correct connections and wire accordingly.

Connect Black or Red Supply Wire to:	Connect White Supply Wire to:
Black	White
*Parallel cord (round & smooth)	*Parallel cord (square & ridged)
Clear, Brown, Gold or Black without tracer	Clear, Brown, Gold or Black with tracer
Insulated wire (other than green) with copper conductor	Insulated wire (other than green) with silver conductor

*Note: When parallel wires (SPT I & SPT II) are used. The neutral wire is square shaped or ridged and the other wire will be round in shape or smooth (see illus.)



- Push fixture to ceiling, carefully passing mounting screw through holes.
- Secure fixture to ceiling with threaded balls.
- Screw short end of threaded pipe with hexnut into coupling at bottom of fixture.
- Raise glass up to fixture carefully passing threaded pipe through hole in glass.
- Slip flat washer over threaded pipe
- Pass trim over threaded pipe. Screw finial onto threaded pipe. (DO NOT over tighten.)

1) COUPER LE COURANT.

IMPORTANT: TOUJOURS couper l'électricité avant de commencer le travail.

- Localiser le coffret à fusibles ou le disjoncteur du domicile. Mettre l'interrupteur principal en position d'Arrêt.
- Dévisser le ou les fusibles (ou mettre le disjoncteur sur Arrêt) qui contrôlent l'alimentation vers le luminaire ou la pièce dans laquelle le travail est effectué.
- Mettre l'interrupteur mural en position d'Arrêt. Si le luminaire à remplacer est doté d'un interrupteur ou d'une chaîne connectée à l'interrupteur, placer ces éléments en position d'Arrêt.


2) Trouver les trous filetés appropriés sur le support de montage. Visser les vis de montage dans les trous taraudés.

3) Fixer le support de montage sur la boîte à prises. (Vis non fournies). Le support de montage peut être réglé afin de positionner correctement le luminaire.

4) Connecter les fils (connecteurs non fournis). Se reporter au tableau ci-dessous pour faire les connexions.

Connecter le fil noir ou rouge de la boîte	Connecter le fil blanc de la boîte
A Noir	A Blanc
*Au cordon parallèle (rond et lisse)	*Au cordon parallèle (à angles droits et strié)
Au transparent, doré, marron, ou noir sans fil distinctif	Au transparent, doré, marron, ou noir avec un fil distinctif
Fil isolé (sauf fil vert) avec conducteur en cuivre	Fil isolé (sauf fil vert) avec conducteur en argent

*Remarque: Avec emploi d'un fil parallèle (SPT I et SPT II). Le fil neutre est à angles droits ou strié et l'autre fil doit être rond ou lisse (Voir le schéma).



- Pousser le luminaire contre le plafond en passant avec précaution les vis dans les trous.
- Bloquer le luminaire contre le plafond avec les boules filetées.
- Visser l'extrémité tube fileté avec l'écrou hexagonal déjà installé dans l'accouplement sur la partie inférieure du luminaire.
- Soulever le verre vers le luminaire en passant soigneusement le tube fileté par le trou dans le verre.
- Passer la rondelle plate sur le tube fileté.
- Passer la garniture inférieure sur le tube fileté et visser l'ornement sur le tube fileté. (NE PAS serrer avec excès).